



# Bridge Assembly




00811 Bridge Assembly 6-string, Complete  
00826 Bridge Cover Chrome  
00827 Bridge Cover Black

S17.pcx



00821 Bridge Assembly, 12-string, Complete  
00826 Bridge Cover Chrome  
00827 Bridge Cover Black

S38.pcx



00813 Channel Bridge 6 String Chrome  
00822 Channel Bridge 12 String Chrome  
00814 Bridge Saddles - 6 Saddle Bridge  
00824 Bridge Saddles - 12 Saddle Bridge  
00826 Bridge Cover Chrome  
00827 Bridge Cover Black  
00829 Base Bridge Chrome  
00830 Base Bridge Black  
05201 Mounting Screw  
05302 Bridge Height Adjustment Screw  
05303 Bridge Intonation Screw - 6 Saddle Bridge  
05305 Bridge Intonation Screw - 12 Saddle Bridge  
06113 Bridge Intonation Spring  
06114 Bridge Height Adjustment Spring